





Schurter




CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S

| | |
|---------------------|---|
| Part Number: | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S |
| Manufacturer/Brand: | Schurter |
| Product description | SWITCH PUSHBUTTON SPST 100MA 42V |
| Datasheets: |  CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S.pdf |
| RoHs Status |  Lead free / RoHS Compliant |
| Ship From | Hong Kong |
| Shipment Way | DHL/Fedex/TNT/UPS/EMS |

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.













Specifications of CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S

| | |
|----------------------------------|---|
| PART NUMBER | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S |
| MANUFACTURER | Schurter |
| DESCRIPTION | SWITCH PUSHBUTTON SPST 100MA 42V |
| LEAD FREE STATUS / ROHS STATUS | Lead free / RoHS Compliant |
| DATA SHEET |  CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S.pdf |
| VOLTAGE RATING - DC | 60V |
| VOLTAGE RATING - AC | 42V |
| TYPE | Capacitive, Illuminated |
| TERMINATION STYLE | Wire Leads |
| SWITCH FUNCTION | Off-On |
| SERIES | CPS |
| PANEL CUTOOUT DIMENSIONS | Circular - 19.10mm Dia |
| PACKAGING | Bulk |
| OPERATING TEMPERATURE | -40°C ~ 60°C |
| MOUNTING TYPE | Panel Mount, Front |
| MOISTURE SENSITIVITY LEVEL (MSL) | 1 (Unlimited) |
| MECHANICAL LIFE | - |
| LEAD FREE STATUS / ROHS STATUS | Lead free / RoHS Compliant |
| INGRESS PROTECTION | IP67 - Dust Tight, Waterproof |
| ILLUMINATION VOLTAGE (NOMINAL) | 5 ~ 28 VDC |
| ILLUMINATION TYPE, COLOR | LED, Cyan/Magenta |
| FEATURES | Ceramic Actuator, Finger Guide, A Symbol |
| ELECTRICAL LIFE | - |
| DETAILED DESCRIPTION | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front |
| CURRENT RATING | 100mA (AC/DC) |
| COLOR - ACTUATOR/CAP | Clear (White Filter/Diffuser) |
| CIRCUIT | SPST |
| ACTUATOR TYPE | Round, Button, Flush |

Related Tags

| | | |
|---|--|--|
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Distributor | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Supplier |
| CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Price | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Pictures | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Image |
| CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S PDF Datasheet | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Download Datasheet | CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Datasheet |
| CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S Stock | Buy CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S | Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S |
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S | Schurter Supplier | Schurter Distributor |
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S | Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1001-S | |

Related Products

| | |
|--|---|
| <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1075-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> | <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1002-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> |
| <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W0000-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> | <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1006-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> |
| <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1074-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> | <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1003-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> |
| <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1077-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> | <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1004-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> |
| <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1005-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> | <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1073-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> |
| <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1076-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> | <div></div> <div>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1007-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: Out stock</div> <div>RFQ</div> |