

**SCHURTER**  
ELECTRONIC COMPONENTS

Schurter

**SCHURTER**  
ELECTRONIC COMPONENTS

CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S

|                     |                                                                                                                               |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Part Number:        | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S                                                                                       |
| Manufacturer/Brand: | Schurter                                                                                                                      |
| Product description | SWITCH PUSHBUTTON SPST 100MA 42V                                                                                              |
| Datasheets:         |  CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S.pdf |
| RoHs Status         |  Lead free / RoHS Compliant                  |
| Ship From           | Hong Kong                                                                                                                     |
| Shipment Way        | DHL/Fedex/TNT/UPS/EMS                                                                                                         |

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

Specifications of CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S

|                                  |                                                                                                                                 |
|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| PART NUMBER                      | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S                                                                                         |
| MANUFACTURER                     | Schurter                                                                                                                        |
| DESCRIPTION                      | SWITCH PUSHBUTTON SPST 100MA 42V                                                                                                |
| LEAD FREE STATUS / ROHS STATUS   | Lead free / RoHS Compliant                                                                                                      |
| DATA SHEET                       |  CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S.pdf |
| VOLTAGE RATING - DC              | 60V                                                                                                                             |
| VOLTAGE RATING - AC              | 42V                                                                                                                             |
| TYPE                             | Capacitive, Illuminated                                                                                                         |
| TERMINATION STYLE                | Wire Leads                                                                                                                      |
| SWITCH FUNCTION                  | Off-On                                                                                                                          |
| SERIES                           | CPS                                                                                                                             |
| PANEL CUTOOUT DIMENSIONS         | Circular - 19.10mm Dia                                                                                                          |
| PACKAGING                        | Bulk                                                                                                                            |
| OPERATING TEMPERATURE            | -40°C ~ 60°C                                                                                                                    |
| MOUNTING TYPE                    | Panel Mount, Front                                                                                                              |
| MOISTURE SENSITIVITY LEVEL (MSL) | 1 (Unlimited)                                                                                                                   |
| MECHANICAL LIFE                  | -                                                                                                                               |
| LEAD FREE STATUS / ROHS STATUS   | Lead free / RoHS Compliant                                                                                                      |
| INGRESS PROTECTION               | IP67 - Dust Tight, Waterproof                                                                                                   |
| ILLUMINATION VOLTAGE (NOMINAL)   | 5 ~ 28 VDC                                                                                                                      |
| ILLUMINATION TYPE, COLOR         | LED, Cyan/Green                                                                                                                 |
| FEATURES                         | Ceramic Actuator, Finger Guide, 4 Symbol                                                                                        |
| ELECTRICAL LIFE                  | -                                                                                                                               |
| DETAILED DESCRIPTION             | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front                                                               |
| CURRENT RATING                   | 100mA (AC/DC)                                                                                                                   |
| COLOR - ACTUATOR/CAP             | Clear (White Filter/Diffuser)                                                                                                   |
| CIRCUIT                          | SPST                                                                                                                            |
| ACTUATOR TYPE                    | Round, Button, Flush                                                                                                            |

Related Tags

|                                                       |                                                            |                                                      |
|-------------------------------------------------------|------------------------------------------------------------|------------------------------------------------------|
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S      | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Distributor        | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Supplier     |
| CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Price         | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Pictures           | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Image        |
| CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S PDF Datasheet | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Download Datasheet | CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Datasheet    |
| CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S Stock         | Buy CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S                | Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S |
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S      | Schurter Supplier                                          | Schurter Distributor                                 |
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S      | Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1031-S      |                                                      |

Related Products

|                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1028-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1027-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |
|  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1033-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1026-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |
|  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1032-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1029-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |
|  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1034-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1036-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |
|  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1025-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1030-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |
|  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1035-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |  <b>SCHURTER</b><br>ELECTRONIC COMPONENTS<br><b>CPS19-LA00A10-SNCCWTWF-AI0CGVAR-W1037-S</b><br>Manufacturers: Schurter<br>Description: SWITCH PUSHBUTTON SPST 100MA 42V<br>In stock: Out stock<br>RFQ |