



**SCHURTER**  
ELECTRONIC COMPONENTS

Schurter

**SCHURTER**  
ELECTRONIC COMPONENTS


CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S

Part Number:	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	 <a href="#">CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S.pdf</a>
RoHs Status	 Lead free / RoHS Compliant
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.






Specifications of CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S

PART NUMBER	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST 100MA 42V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
DATA SHEET	 <a href="#">CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S.pdf</a>
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TYPE	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
SWITCH FUNCTION	Off-On
SERIES	CPS
PANEL CUTOOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ILLUMINATION VOLTAGE (NOMINAL)	5 ~ 28 VDC
ILLUMINATION TYPE, COLOR	LED, Cyan/Red
FEATURES	Ceramic Actuator, Finger Guide, 5 Symbol
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)
CIRCUIT	SPST
ACTUATOR TYPE	Round, Button, Flush

Related Tags

Schurter CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Distributor	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Supplier
CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Price	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Pictures	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Image
CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S PDF Datasheet	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Download Datasheet	CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Datasheet
CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S Stock	Buy CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S	Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S
Schurter CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S	Schurter Supplier	Schurter Distributor
Schurter CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S	Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1032-S	

Related Products

 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1027-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1036-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1030-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1026-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1031-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1037-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1038-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1028-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1029-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1034-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1035-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 <b>SCHURTER</b> ELECTRONIC COMPONENTS <b>CPS19-LA00A10-SNCCWTWF-AI0CRVAR-W1033-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ