**Schurter** 



CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S

CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Part Number:

Schurter

Manufacturer/Brand:

SWITCH PUSHBUTTON SPST 100MA 42V Product description

DHL/Fedex/TNT/UPS/EMS

CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S.pdf

Lead free / RoHS Compliant RoHs Status

Hong Kong Ship From

Shipment Way

Datasheets:

**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

**5.SCHURTER** ELECTRONIC COMPONENTS

S.SCHURTER

	Specifications of CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S
PART NUMBER	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST 100MA 42V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
DATA SHEET	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S.pdf
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TYPE	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
SWITCH FUNCTION	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSI	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ILLUMINATION VOLTAGE (NOMINAL	5 ~ 28 VDC
ILLUMINATION TYPE, COLOR	LED, White/Magenta
FEATURES	Ceramic Actuator, Add Symbol
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)
CIRCUIT	SPST
ACTUATOR TYPE	Round, Button, Flush

**Related Tags** 

Schurter CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Distributor	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Supplier
CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Price	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Pictures	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Image
CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S PDF Datasheet	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Download Datasheet	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Datasheet
CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S Stock	Buy CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S	Buy Schurter CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S
Schurter CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S	Schurter Supplier	Schurter Distributor
Schurter CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S	Schurter Inc. CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1037-S	

/1037-S				
churter CPS19-LA00A10-SNCCWTNF-AI0WMVAR- /1037-S		Schurter Inc. CPS19-LA00A10-SNCCWTNF-AI0WMVAF W1037-S		-
		Relate	d Products	
	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1036-S  Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock  RFQ		S.SCHURTER ELECTRONIC COMPONENTS	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1043-S
S.SCHURTER ELECTRONIC COMPONENTS				Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock
				RFQ
	CPS19-LA00A10-SNCC\ W1040-S	NTNF-AIOWMVAR-		CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1038-S
S.SCHURTER ELECTRONIC COMPONENTS	Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock  RFQ		S.SCHURTER ELECTRONIC COMPONENTS	Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock
				RFQ
S.SCHURTER ELECTRONIC COMPONENTS	CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1033-S			CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1039-S
	Manufacturers: Schurter Description: SWITCH PUSHBU In stock: Out stock	TTON SPST 100MA 42V	S.SCHURTER ELECTRONIC COMPONENTS	Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock
	RFQ			RFQ
	CPS19-LA00A10-SNCC\ W1031-S	NTNF-AIOWMVAR-		CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1042-S
S.SCHURTER	Manufacturers: Schurter		S.SCHURTER	Manufacturers: Schurter

# Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V

# In stock: Out stock **RFQ**

In stock: Out stock **RFQ** 

CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1034-S

### W1035-S S.SCHURTER Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V

W1032-S

In stock: Out stock

S.SCHURTER

In stock: Out stock

CPS19-LA00A10-SNCCWTNF-AI0WMVAR-

CPS19-LA00A10-SNCCWTNF-AI0WMVAR-

**RFQ** 

S.SCHURTER

# Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock

**RFQ** 

Manufacturers: Schurter

CPS19-LA00A10-SNCCWTNF-AI0WMVAR-W1041-S

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V

**RFQ** 

**S.SCHURTER** 

Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock

**RFQ** 

Manufacturers: Schurter













