





Schurter


## CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S

Part Number:	CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S
Manufacturer/Brand:	Schurter
Product description:	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	 <a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S.pdf</a>
RoHS Status:	 Lead free / RoHS Compliant
Ship From:	Hong Kong
Shipment Way:	DHL/Fedex/TNT/UPS/EMS

[REQUEST FOR QUOTATION](#)

Image may be representation. See specifications for product details.

### Specifications of CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S

PART NUMBER	CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST 100MA 42V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
DATA SHEET	 <a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S.pdf</a>
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TYPE	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
SWITCH FUNCTION	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ILLUMINATION VOLTAGE (NOMINAL)	5 ~ 28 VDC
ILLUMINATION TYPE, COLOR	LED, Cyan/Magenta
FEATURES	Ceramic Actuator, Finger Guide, Arrow Symbol
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)
CIRCUIT	SPST
ACTUATOR TYPE	Round, Button, Flush

### Related Tags

<a href="#">Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S</a>	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Distributor</a>	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Supplier</a>
<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Price</a>	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Pictures</a>	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Image</a>
<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S PDF Datasheet</a>	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Download Datasheet</a>	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Datasheet</a>
<a href="#">CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S Stock</a>	<a href="#">Buy CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S</a>	<a href="#">Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S</a>
<a href="#">Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S</a>	<a href="#">Schurter Supplier</a>	<a href="#">Schurter Distributor</a>
<a href="#">Schurter CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S</a>	<a href="#">Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1044-S</a>	

### Related Products

 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1039-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1048-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1046-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1047-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1041-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1038-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1042-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1050-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1040-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1045-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1043-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS19-LA00A10-SNCCWTWF-AI0CMVAR-W1049-S</b>  Manufacturers: Schurter  Description: SWITCH PUSHBUTTON SPST 100MA 42V  In stock: Out stock</p> <p><a href="#">RFQ</a></p>