



**SCHURTER**
ELECTRONIC COMPONENTS

Schurter

**SCHURTER**
ELECTRONIC COMPONENTS


CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S

| | |
|---------------------|---|
| Part Number: | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S |
| Manufacturer/Brand: | Schurter |
| Product description | SWITCH PUSHBUTTON SPST 100MA 42V |
| Datasheets: |  CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S.pdf |
| RoHs Status |  Lead free / RoHS Compliant |
| Ship From | Hong Kong |
| Shipment Way | DHL/Fedex/TNT/UPS/EMS |

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.






Specifications of CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S

| | |
|----------------------------------|---|
| PART NUMBER | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S |
| MANUFACTURER | Schurter |
| DESCRIPTION | SWITCH PUSHBUTTON SPST 100MA 42V |
| LEAD FREE STATUS / ROHS STATUS | Lead free / RoHS Compliant |
| DATA SHEET |  CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S.pdf |
| VOLTAGE RATING - DC | 60V |
| VOLTAGE RATING - AC | 42V |
| TYPE | Capacitive, Illuminated |
| TERMINATION STYLE | Wire Leads |
| SWITCH FUNCTION | Off-On |
| SERIES | CPS |
| PANEL CUTOOUT DIMENSIONS | Circular - 19.10mm Dia |
| PACKAGING | Bulk |
| OPERATING TEMPERATURE | -40°C ~ 60°C |
| MOUNTING TYPE | Panel Mount, Front |
| MOISTURE SENSITIVITY LEVEL (MSL) | 1 (Unlimited) |
| MECHANICAL LIFE | - |
| LEAD FREE STATUS / ROHS STATUS | Lead free / RoHS Compliant |
| INGRESS PROTECTION | IP67 - Dust Tight, Waterproof |
| ILLUMINATION VOLTAGE (NOMINAL) | 5 ~ 28 VDC |
| ILLUMINATION TYPE, COLOR | LED, Cyan/Yellow |
| FEATURES | Ceramic Actuator, Finger Guide, UP Symbol |
| ELECTRICAL LIFE | - |
| DETAILED DESCRIPTION | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front |
| CURRENT RATING | 100mA (AC/DC) |
| COLOR - ACTUATOR/CAP | Clear (White Filter/Diffuser) |
| CIRCUIT | SPST |
| ACTUATOR TYPE | Round, Button, Flush |

Related Tags

| | | |
|---|--|--|
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Distributor | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Supplier |
| CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Price | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Pictures | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Image |
| CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S PDF Datasheet | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Download Datasheet | CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Datasheet |
| CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S Stock | Buy CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S | Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S |
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S | Schurter Supplier | Schurter Distributor |
| Schurter CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S | Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1067-S | |

Related Products

| | |
|---|--|
|  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1061-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1069-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |
|  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1063-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1070-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |
|  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1066-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1062-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |
|  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1072-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1073-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |
|  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1064-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1068-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |
|  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1071-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |  SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0CEVAR-W1065-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ |