

**SCHURTER**
ELECTRONIC COMPONENTS

Schurter

**SCHURTER**
ELECTRONIC COMPONENTS

CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S

Part Number:	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	 CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S.pdf
RoHs Status	 Lead free / RoHS Compliant
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

Specifications of CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S

PART NUMBER	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST 100MA 42V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
DATA SHEET	 CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S.pdf
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TYPE	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
SWITCH FUNCTION	Off-On
SERIES	CPS
PANEL CUTOOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ILLUMINATION VOLTAGE (NOMINAL)	5 ~ 28 VDC
ILLUMINATION TYPE, COLOR	LED, Red/Yellow
FEATURES	Ceramic Actuator, Finger Guide, START Symbol
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)
CIRCUIT	SPST
ACTUATOR TYPE	Round, Button, Flush

Related Tags

Schurter CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Distributor	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Supplier
CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Price	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Pictures	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Image
CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S PDF Datasheet	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Download Datasheet	CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Datasheet
CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S Stock	Buy CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S	Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S
Schurter CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S	Schurter Supplier	Schurter Distributor
Schurter CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S	Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1072-S	

Related Products

 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1074-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1075-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1069-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1076-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1068-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1073-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1071-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1070-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1066-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0WBVAR-W0000-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1067-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 SCHURTER ELECTRONIC COMPONENTS CPS19-LA00A10-SNCCWTWF-AI0RYVAR-W1077-S Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ