



**SCHURTER**  
ELECTRONIC COMPONENTS

Schurter

**SCHURTER**  
ELECTRONIC COMPONENTS


CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S

Part Number:	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	 CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S.pdf
RoHs Status	 Lead free / RoHS Compliant
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.













Specifications of CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S

PART NUMBER	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST 100MA 42V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
DATA SHEET	 CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S.pdf
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TYPE	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
SWITCH FUNCTION	Off-On
SERIES	CPS
PANEL CUTOOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ILLUMINATION VOLTAGE (NOMINAL)	5 ~ 28 VDC
ILLUMINATION TYPE, COLOR	LED, White/Cyan
FEATURES	Ceramic Actuator, Finger Guide, B Symbol
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)
CIRCUIT	SPST
ACTUATOR TYPE	Round, Button, Flush

Related Tags

Schurter CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Distributor	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Supplier
CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Price	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Pictures	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Image
CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S PDF Datasheet	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Download Datasheet	CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Datasheet
CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S Stock	Buy CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S	Buy Schurter CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S
Schurter CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S	Schurter Supplier	Schurter Distributor
Schurter CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S	Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1002-S	

Related Products

<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1007-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>	<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1006-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>
<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1008-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>	<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WBVAR-W1074-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>
<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WBVAR-W1076-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>	<div></div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W0000-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>
<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WBVAR-W1075-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>	<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WBVAR-W1077-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>
<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1005-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>	<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1001-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>
<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1004-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>	<div><b>SCHURTER</b> ELECTRONIC COMPONENTS</div> <div><b>CPS19-LA00A10-SNCCWTWF-AI0WCVAR-W1003-S</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock</div> <div>RFQ</div>