



Honeywell
Honeywell Sensing and Productivity Solutions

Honeywell

Productivity Solutions


3455RM 01380027

Part Number:	3455RM 01380027
Manufacturer/Brand:	Honeywell Sensing and Productivity Solutions
Product description:	MANUAL RESET THERMOSTAT
Datasheets:	 3455RM 01380027.pdf
RoHS Status:	 Lead free / RoHS Compliant
Ship From:	Hong Kong
Shipment Way:	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.


Specifications of 3455RM 01380027

PART NUMBER	3455RM 01380027
MANUFACTURER	Honeywell Sensing and Productivity Solutions
DESCRIPTION	MANUAL RESET THERMOSTAT
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
DATA SHEET	 3455RM 01380027.pdf
TOLERANCE	-
TERMINATION STYLE	Solder Lug
SWITCHING TEMPERATURE	-
SWITCHING CYCLES	-
SERIES	3455RM
RESET TEMPERATURE	Manual Reset
PACKAGE / CASE	Cylinder
OTHER NAMES	3455RM01380027
MOUNTING TYPE	Chassis Mount
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MANUFACTURER STANDARD LEAD TIME	10 Weeks
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
CURRENT RATING - DC	-
CURRENT RATING - AC	-
CIRCUIT	-

Related Tags

Honeywell Sensing and Productivity Solutions 3455RM 01380027	3455RM 01380027 Distributor	3455RM 01380027 Supplier
3455RM 01380027 Price	3455RM 01380027 Pictures	3455RM 01380027 Image
3455RM 01380027 PDF Datasheet	3455RM 01380027 Download Datasheet	3455RM 01380027 Datasheet
3455RM 01380027 Stock	Buy 3455RM 01380027	Buy Honeywell Sensing and Productivity Solutions 3455RM 01380027
Honeywell Sensing and Productivity Solutions 3455RM 01380027	Honeywell Sensing and Productivity Solutions Supplier	Honeywell Sensing and Productivity Solutions Distributor
Honeywell Sensing and Productivity Solutions 3455RM 01380027	HONEYWELL 3455RM 01380027	Honeywell Sensing and Control EMEA 3455RM 01380027
Honeywell Sensing and Productivity Solutions T&M 3455RM 01380027		

Related Products

<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 02570023</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 01210014</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 02090012</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 01210013</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 01130105</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 01210027</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 02890047</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 02570008</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 02570066</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: right;"> <p style="margin: 0;">3455RM 02850059</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: 6 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>
<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 01210006</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>	<div style="display: flex; justify-content: space-between; align-items: center;"> Honeywell <div> <p style="margin: 0;">3455RM 01210012</p> <p style="font-size: 0.8em; margin: 0;">Manufacturers: Honeywell Sensing and Productivity Solutions Description: MANUAL RESET THERMOSTAT In stock: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px; border-radius: 5px; width: 50px; margin: 0;">RFQ</p> </div> </div>